

Bema square surface mounted range of LED slim ceiling lights are a perfect fit for ambient lighting applications. The die cast aluminium housing is ideal for better thermal management. High lumen output & CCT options make this versatile for superior glare free indoor lighting solutions.

Product Description

- · LED ceiling surface mounted indoor luminaire with soft light.
- Luminaire made of die-cast aluminium for better thermal management.
- High efficiency diffuser for glare free, uniform light distribution.
- · High lumen output, Integrated with 2835 LEDs.
- High PF constant current LED driver.
- · Cable entries for through-wiring of mains supply cable
- Prewired with constant current LED driver and suitable for operation on 240V, 50Hz single phase ac supply.
- Ordering guide: KL-27333-CCT (Colour Temperature)
- · Available CCT: 3000K, 4000K, 6000K.



Product Benefits

- · Attractive high quality housing and optics.
- · Visual comfort with maximum energy saving
- Sturdy construction in order to maintain performance of the luminaire and to reduce maintenance costs.
- · Quick & simple installation.
- Flexible deployment options with a wide spectrum of applications.

Area of Application

Lobbies & Foyers, Retail Sector, Corridors, Residential, Receptions, Internal passages, Hospitality Industry, Commercial & Business Centers, etc.

Available Finish

White epoxy polyester powder coating.

Bema - Down Lighter



K-LiTEBema Square





Technical Specifications

General

ID : 27333
System Wattage : 36W LED
Driver Integral : Constant Current
Operating Voltage : 100-240Vac
Operating Temperature : -15°C~+50°C

Physical

Body : Die-Cast Aluminium
Diffuser : Translucent Polystyrene
Mounting : Ceiling Surface / Fixed
Finish : White epoxy polyester

powder coating

Light Source

Light Source : EDISON CRI (Ra) :>80

LED Colour Temperature : 3000K / 4000K / 6000K

Driver


Power Supply : Integral Input Voltage : 230-240Vac Frequency : 50-60Hz Power Factor :>0.90 THD :<10% Surge Protection : 2.5KV Efficiency :>80%

Dimmable options : Triac / 1-10V / Dali

Optical Performance

Beam Angle : 120° (Fixed)





□211 • 51

Note: It is our constant endeavor to upgrade the performance of our products. For the latest technical information, IES files and product updates please refer to the website at www.klite.in